

RS-232 Interface and Decoupling Caps



Auxiliary Memory Board



Power Supply Board

(This page left intentionally blank.)

Index

A

AC Power Cord 4-13
Accessories
  Alternate 4-15
  DC Power 4-16
  Optional 4-15
  Required 4-14
Altitude
  Setting 4-10
Altitude Compensation 3-5
Audible Alert 6-7
Auto-CPAP Mode 1-3, 3-4, 4-5
  Pressure Limit Settings 4-6
Auto-off
  Setting 4-11
Auto-on
  Setting 4-11
Auxiliary Memory Board Schematics B-10, B-11
Available Memory 4-18
Available Memory Display 4-18

B

Battery
  12 Volt A-5
  Specifications A-5
Battery Cable Adapter A-3
Blower Assembly
  Replacing 7-35, 7-36, 7-37
Blower Screen 8-4
Blower Time Meter 4-21
Bottom Enclosure
  Replacing 7-16
Bottom Strip
  Replacing 7-11, 7-12

C

Cautions 2-5, 7-8
Change Settings Screen 8-4
Circuit Accessories
  Alternate 4-15
  Optional 4-15
  Required 4-14
Clear Time Meters and Deep Sleep Screens
  Access Flow Chart 4-20
Clear Time Meters Screen 4-19, 4-20, 4-21
Connect Pressure Line 6-5, 6-11
Continuous Positive Airway Pressure (CPAP) 1-3, 2-3, 3-8, 7-3
Control Pad 3-9, 7-20
  Replacing 7-23, 7-24, 7-25

Index (Continued)

CPAP Mode 1-3, 4-5
Pressure Settings 4-6
Ramp Time Settings 4-8
Setting Minimum Ramp Pressure 4-9

D

DC Battery Adapter Cable 4-16
DC Power Cord 4-16, 6-9
DC Power Supply
Regulated A-5
Deep Sleep Screen 4-19, 4-20, 4-21
Delay Time Setting
Split Night with Auto-CPAP Mode 4-9
Digital Manometer
Specifications A-4
Digital Multimeter
Specifications A-5
Display 6-8
Display Assembly 7-20
Replacing 7-21, 7-22
Display Language
Setting 4-5
Display Screens 4-5

E

EEPROM Chip 3-9
Enclosure Insert
Replacing 7-41, 7-42
Encore Data Management Software 1-3
Equipment 8-5
Equipment Setup 8-5
Error Code Chart 6-13, 6-14, 6-15
Exit Settings 4-13

F

Filter Cap
Removing 5-4
Replacing 7-13, 7-14
Filters
Cleaning 5-3
Disposable 5-3
Pollen 5-3
Removing 5-3
Replacing 5-3
Reusable 5-3
Ultra-fine 5-3
Flow Chart
Clear Time Meters and Deep Sleep Screens Access 4-20
Installation 7-10
Removal 7-9
Functions 3-4

G

Great Performers Calibration Station 6-3, 6-9, 6-10, 6-11, 6-12, 6-13, 6-14, 6-15, A-3

Index (Continued)

H

Humidifier
Adding 4-17

I

Indicator 6-7
Installation Flow Chart 7-10
Intermittent Power Supply Problem 6-8

L

Light-Emitting Diode (LED) 1-3, 3-8, 4-4, 8-3
Liquid Crystal Display (LCD) 1-3, 3-9
Low Power Sleep Mode 4-21

M

Main Printed Circuit Assembly (Main PCA) 3-9
Replacing 7-27, 7-28, 7-29
Main Printed Circuit Assembly (PCA) Schematics B-4, B-5, B-6, B-7, B-8, B-9
Manometer
Digital A-4
Mask Alert
Setting 4-10
Mask Disconnected 6-4
Maximum Pressure Test 8-7
Minimum Pressure Test 8-6
Minimum Ramp Pressure
Setting 4-9
Mode 1-3
12 VDC 6-9
Auto-CPAP 1-3
CPAP 1-3
Setting 4-5
Split Night with Auto-CPAP 1-3
Multimeter
Digital A-5

N

Noise 6-9
Notes 2-5

O

O_2 Enrichment Port A-3
Obstructive Sleep Apnea (OSA) 1-3
Odor 6-10
Operating Time 4-18
Operating Time Display 4-18
Outlet Air Temperature 6-10
Outlet Port
Replacing 7-33, 7-34
Oxygen
Adding 4-17

Index (Continued)

P

Patient Data
Setting 4-12
Patient Setup Menu 4-5
Power Cord
DC A-3
Power Supply 3-10
DC Regulated A-3
Power Supply Printed Circuit Assembly (PCA) 3-10
Replacing 7-38, 7-39, 7-40
Pressure 3-6
Setting 4-6
Pressure Limit Settings
Auto-CPAP Mode 4-6
Pressure Offset 6-11
Pressure On / Off Button 4-11, 4-19, 8-4, 8-7, 8-9
Pressure Port 8-3
Pressure Related Problems 6-11
Pressure Screen 8-7
Pressure Settings
CPAP Mode 4-6
Split Night with Auto-CPAP Mode 4-7
Pressure Tubing 8-3
Replacing 7-30, 7-31, 7-32
Pressure Variation 6-12
Preventive Maintenance Schedule 5-7
Procedure
System Final Test 8-5
User Interface Checkout 8-3

R

Ramp 3-5
Ramp Button 8-8
Ramp Operation 4-8
Ramp Pressure 6-12
Setting 4-9
Ramp Time Settings
CPAP Mode 4-8
Regulated DC Power Supply
Specifications A-5
Removal Flow Chart 7-9
Run-in Test 8-8

S

Save Settings 4-13
Schematic Statement B-3
Schematics
Auxiliary Memory Board, 1 of 1 ..... B-10
Filtering, 5 of 6 ..... B-8
Main PCA Power Supply, 2 of 6 ..... B-5
Microprocessor, 1 of 6 ..... B-4
Motor Controller, 3 of 6 ..... B-6
Pressure Sensor, 4 of 6 ..... B-7
RS-232 Interface and Decoupling Caps, 6 of 6 ..... B-9
Self-Diagnostic Test 4-4
Specifications
Altitude Compensation 3-5
Compliance Meter 3-5

Index (Continued)

Electrical 3-4
Environmental 3-4
Functions 3-4
Fuses 3-4
Physical 3-4
Pressure 3-6
Ramp 3-5
Therapy Memory 3-6
Split Night with Auto-CPAP Mode 1-3, 3-4, 4-5
Delay Time Setting 4-9
Pressure Settings 4-7
Supplies A-3
System
Cleaning 5-3
System Error # # 6-5
System Error 7 8-6
System Final Test 8-5
System Final Test Data Sheet 8-10
System Level Problems 6-4, 6-5
System Power Up 4-3
System Repair Kits 7-5, 7-6, 7-7
System Setup Procedure 4-13

T

Technical Support 1-4
Test Equipment
Acceptable A-4
Test Orifice 8-3, A-3
Therapy Hours
Setting 4-12
Total 4-18
Therapy Menu 4-3
Therapy Setup Menu 4-5, 4-13
Therapy Time Meter 4-21
Time
Setting 4-8
Tools A-3
Top Enclosure
Replacing 7-17, 7-18, 7-19, 7-20
Total Blower Time 4-18
Total Operating Time 4-18
Troubleshooting Flow Chart 6-6
Troubleshooting Table 6-7, 6-8, 6-9, 6-10, 6-11, 6-12

U

Usage Menu 8-8
User Interface Checkout Procedure 6-7, 6-12, 8-3

V

Virtuoso LX 1-4, 2-4, 2-5, 3-7, 3-9, 4-4, 4-14, 4-16, 4-17, 4-18, 4-19, 5-6, 6-4, 6-5, 7-4, 7-5, 7-6, 7-7, 7-8, 8-5, 8-8
Virtuoso LX Smart CPAP System (Virtuoso LX) 1-3, 2-3, 3-8, 4-3, 5-3, 7-3, 8-3, A-3
Virtuoso LX Smart CPAP System Exploded View 7-4
Virtuoso LX Smart CPAP System Repair Kits 7-5, 7-6, 7-7

Index (Continued)

W

Warnings 7-8
Cleaning 2-4
Operational 2-3
Safety 2-3
Service 2-4
Watt Meter A-3
Specifications A-4
World Wide Web 1-4, 7-3